




138109

## polar white, glossy

Description	Pack qty.	Art No.
1930 Frame 1-gang, Polar White Glossy	10	<b>138109</b>
RA 1F F ELEKTRO-EINS S1930 P-W	10	<b>138209</b>
1930 Frame 2-gang, Polar White Glossy	2	<b>138129</b>
1930 Frame 3-gang, Polar White Glossy	2	<b>138139</b>
1930 End Frame, Polar White Glossy	10	<b>138149</b>
1930 Centre Frame Polar White Glossy	10	<b>138159</b>
RAHMEN 1F S1930 P-W	10	<b>138199</b>



138101

## black glossy

Description	Pack qty.	Art No.
1930 Frame 1-gang, Black Glossy	10	<b>138101</b>
RA 1F F ELEKTRO-EINS S1930 SCHW	10	<b>138201</b>
1930 Frame 2-gang, Black Glossy	2	<b>138121</b>
1930 Frame 3-gang, Black Glossy	2	<b>138131</b>
1930 End Frame, Black Glossy	10	<b>138141</b>
1930 Centre Frame Black Glossy	10	<b>138151</b>
RAHMEN 1F S1930 SCHWARZ	10	<b>138191</b>



138169

## polar white, glossy, porcelain

Description	Pack qty.	Art No.
1930 Porcelain Frame Polar White Glossy	1	<b>138169</b>



138165

## black glossy, porcelain

Description	Pack qty.	Art No.
1930 Porcelain Frame, Black Glossy	1	<b>138165</b>