



1091

1-gang

Description	Pack qty.	Art No.
Serie Glas Frame, 1-gang Clear Glossy	10	1091
RAHMEN GS	1	109199
Serie Glas End Frame, Clear Glossy	10	109200
Serie Glas Centre Frame, Clear Glossy	10	109300



1090

1-gang cover plate for rotary switch

Description	Pack qty.	Art No.
Coverplate for rotary switch clear glass	10	1090



1102

2-gang

Description	Pack qty.	Art No.
Serie Glas Frame, 2-gang Clear Glossy	2	1102



1095

Centre cover plate for rotary switch

Description	Pack qty.	Art No.
Glass Centre Cover Plate Rotary Sw Clear	10	1095



1094

End cover plate for rotary switch

Description	Pack qty.	Art No.
Glass End Cover Plate, Rotary Sw Clear	10	1094