



1221

Push button/lightsignal E10

Description	Pack qty.	Art No.
LENS CLEAR GLASS-SERIES	10	1221
LENS CLEAR GLASS-SERIES	10	1222
BUTTON NEUTRAL "GLASS"	10	1225
BUTTON GLAS/PALAZZO/1930	10	1226
BUTTON GLAS/PALAZZO/1930	10	1227
BUTTON RED GLASS-SERIES	10	1229
MOM.CONT.SW./PILOT LAMP	1	5104
BUTTON BROWN GLASS-SERIES	10	122501
KNOB F.PUSHB. TRANSPARENT	10	122902
MOM.CONT.SW./PILOT LAMP	1	510401



16402079

Electronic hotel card switch

Description	Pack qty.	Art No.
Relais- hotelcard switch R. classic PW	1	16402079
Relais- hotelcard switch R. classic	1	16402035

