

Berker Serie 1930 / Glass / R.Classic

Berker Glass series today stands for switches that are the epitome of understated elegance. The origins of the Berker Serie 1930 can be traced back to the 1930s. The porcelain variant is made together with the famous German brand, Rosenthal.

	Page
Socket outlet (SCHUKO)	3
Socket outlet (international)	4
Light controls	5
Centre plate	6
Berker Serie 1930 frame	9
Berker Serie Glass frame	10
Berker R.Classic frame	11
Surface installation	13
Accessories	14



4755



SCHUKO

Description	Pack qty.	Art No.
CHILD SOCK.SKL GLASS PW	10	4755
SCHUKO SO 1930/Glasseries/Palazzo PW	10	414520
SCHUKO S/outlet-1930/Glas/Palazzo black	10	414521
SCHUKO socket outlet	10	474520
SCHUKO socket outlet	10	474521
CHILD SOCK.SKL GLASS BROW	10	475501
SKO STD M SLK R.1 SCHW	10	41452045
SKO STD M SLK R.1 P-W	10	41452089
SCHUKO soc. out., R.classic, bl glossy	10	47452045
SCHUKO soc. out., R.classic, pw glossy	10	47452089
SKO STD M ERHBS R.1 SCHW	10	47552045
SCHUKO soc.out., R.classic , pw glossy	10	47552089



47442045



SCHUKO with hinged cover

Description	Pack qty.	Art No.
SKO STD M KLD U ERHBS R.1 SCHW	10	47442045
SKO STD M KLD U ERHBS R.1 P-W	10	47442089



41092045



SCHUKO with LED orientation light

Description	Pack qty.	Art No.
SKO-STD M AMBEL SRBKL R.1 SCHW GLÄ	10	41092045
SKO-STD M AMBEL SRBKL R.1 P-W GLÄ	10	41092089

Socket outlet with earthing pin

Description	Pack qty.	Art No.
SOCKET B/F GLASS PW	10	676579
SOCKET B/F GLASS PW	10	676879
2P STD+E-ST KI GS E-BRAUN	10	67657901
SOCKET B/F GLASS PW	10	67687901
STD 2P E-ST M STKL ERHBS R.1 P-W	10	6768792089
STD 2P E-ST M STKL ERHBS R.1 SCHW	10	6768792045
STD 2P E-ST M SLK ERHBS R.1 P-W	10	6765792089
STD 2P E-ST M SLK ERHBS R.1 SCHW	10	6765792045



676579





1221

Push button/lightsignal E10

Description	Pack qty.	Art No.
LENS CLEAR GLASS-SERIES	10	1221
LENS CLEAR GLASS-SERIES	10	1222
BUTTON NEUTRAL "GLASS"	10	1225
BUTTON GLAS/PALAZZO/1930	10	1226
BUTTON GLAS/PALAZZO/1930	10	1227
BUTTON RED GLASS-SERIES	10	1229
MOM.CONT.SW./PILOT LAMP	1	5104
BUTTON BROWN GLASS-SERIES	10	122501
KNOB F.PUSHB. TRANSPARENT	10	122902
MOM.CONT.SW./PILOT LAMP	1	510401



16402079


Electronic hotel card switch

Description	Pack qty.	Art No.
Relais- hotelcard switch R. classic PW	1	16402079
Relais- hotelcard switch R. classic	1	16402035



Blank plate

Description	Pack qty.	Art No.
BLANK PLATE 1930 POLAR W.	20	100920
BLANK PLATE 1930 BROWN	20	100921
BLANK PLATE 1930 POLAR W.	10	67100920
BLANK PLATE 1930 BROWN	10	67100921



100920



centre plate for cable outlet

Description	Pack qty.	Art No.
CENT.PL.TELSOCKET/GLASS/W	10	1037
CENT.PL.TELSOCKET/GLASS/B	10	103701



1037

For aerial socket outlet

Description	Pack qty.	Art No.
CENTRE PLATE 1930 PW	10	103920
CENTRE PLATE 1930 BROWN	10	103921
CENT.PL.F.ANTENNA SOCKET	10	106420
CENT.PL.F.ANTENNA SOCKET	10	106421



103920

For FCC (RJ45) outlets


Description	Pack qty.	Art No.
CENTRE PL.GL/PAL. 1930 PW	10	1407
CENTRE PL.GL/PAL/1930 PW	10	1409
CENT.PL.FOR FCC SOCKET	10	140701
CENTRE PL.GL/PAL/1930 BLA	10	140901



1407

For loudspeaker outlet

Description	Pack qty.	Art No.
Z-ST F LSP-STD RD 1F R.1 SCHW	10	11962035
Z-ST F LSP-STD RD 1F R.1 P-W	10	11962079




11962035



11372035

**For rotary dimmer incl. setting knob**

Description	Pack qty.	Art No.
Z-ST M KNF F DZS R.1 SCHW	10	11372035
Z-ST M KNF F DZS R.1 P-W	10	11372079



450820

Miniature connector

Description	Pack qty.	Art No.
Miniature connector insert with centre p	10	450820
Miniature connector insert with centre p	10	450821



10012004

R.CLASSIC - Cover with toggle for rotary switch/push button

Description	Pack qty.	Art No.
Cover Plate/Toggle Stainless Steel/Black	1	10012004
Cover Plate/Toggle Stainless/Polar White	1	10012014
Cover Plate with Toggle Black Glossy	1	10012045
Cover Plate with Toggle Glass Black	1	10012055
Cover Plate/Toggle Aluminium/Polar White	1	10012074
Cover Plate/Toggle, Polar White Glass	1	10012083
Cover Plate/Toggle Aluminium/Black	1	10012084
Cover Plate/Toggle Polar White Glossy	1	10012089



1812

Rotary knob

Description	Pack qty.	Art No.
Brass toggle - Serie Glas brass	1	1812
Chr tog, Serie Glas, bra, chr-pltd	1	181201



1647

Serie 1930/Glass - with toggle for rotary switch/push button

Description	Pack qty.	Art No.
C/p w/toggle for rotary&spring-return PB	1	1647
Centre Plate with Toggle, Black Glossy	1	164701
C/p w/toggle for rotary&spring-return PB	1	164765
C/p w/toggle for rotary&spring-return PB	1	164769

with TAE outcut

Description	Pack qty.	Art No.
CENT.PL.TELECOMM.GLASS WH	10	1040
CENT.PL.TELECOMM.GLASS BR	10	104001



1040






138109

polar white, glossy

Description	Pack qty.	Art No.
1930 Frame 1-gang, Polar White Glossy	10	138109
RA 1F F ELEKTRO-EINS S1930 P-W	10	138209
1930 Frame 2-gang, Polar White Glossy	2	138129
1930 Frame 3-gang, Polar White Glossy	2	138139
1930 End Frame, Polar White Glossy	10	138149
1930 Centre Frame Polar White Glossy	10	138159
RAHMEN 1F S1930 P-W	10	138199



138101

black glossy

Description	Pack qty.	Art No.
1930 Frame 1-gang, Black Glossy	10	138101
RA 1F F ELEKTRO-EINS S1930 SCHW	10	138201
1930 Frame 2-gang, Black Glossy	2	138121
1930 Frame 3-gang, Black Glossy	2	138131
1930 End Frame, Black Glossy	10	138141
1930 Centre Frame Black Glossy	10	138151
RAHMEN 1F S1930 SCHWARZ	10	138191



138169

polar white, glossy, porcelain

Description	Pack qty.	Art No.
1930 Porcelain Frame Polar White Glossy	1	138169




138165

black glossy, porcelain

Description	Pack qty.	Art No.
1930 Porcelain Frame, Black Glossy	1	138165

1-gang

Description	Pack qty.	Art No.
Serie Glas Frame, 1-gang Clear Glossy	10	1091
RAHMEN GS	1	109199
Serie Glas End Frame, Clear Glossy	10	109200
Serie Glas Centre Frame, Clear Glossy	10	109300



1091

1-gang cover plate for rotary switch

Description	Pack qty.	Art No.
Coverplate for rotary switch clear glass	10	1090



1090

2-gang

Description	Pack qty.	Art No.
Serie Glas Frame, 2-gang Clear Glossy	2	1102



1102

Centre cover plate for rotary switch

Description	Pack qty.	Art No.
Glass Centre Cover Plate Rotary Sw Clear	10	1095




1095

End cover plate for rotary switch

Description	Pack qty.	Art No.
Glass End Cover Plate, Rotary Sw Clear	10	1094



1094



10112084

aluminum / black

Description	Pack qty.	Art No.
Frame 1-gang Aluminium/Black	10	10112084
Frame 2-gang Aluminium/Black	10	10122084
Frame 3-gang Aluminium/Black	10	10132084



10112074

aluminum / polar white

Description	Pack qty.	Art No.
Frame 1-gang Aluminium/Polar White	10	10112074
Frame 2-gang Aluminium/Polar White	10	10122074
Frame 3-gang Aluminium/Polar White	10	10132074



10112016

glass, black

Description	Pack qty.	Art No.
Frame 1-gang Glass Black (R.Classic)	10	10112016
Frame 2-gang Glass Black (R.Classic)	5	10122016
Frame 3-gang Glass Black (R.Classic)	5	10132016



10112009

glass, polar white

Description	Pack qty.	Art No.
Frame 1-gang Glass Polar White	10	10112009
Frame 2-gang Glass Polar White	5	10122009
Frame 3-gang Glass Polar White	5	10132009



10112045

plastic, black

Description	Pack qty.	Art No.
Frame 1-gang Black Glossy (R.Classic)	10	10112045
Frame 2-gang Black Glossy (R.Classic)	2	10122045
Frame 3-gang Black Glossy (R.Classic)	2	10132045

plastic, polar white


Description	Pack qty.	Art No.
Frame 1-gang Polar White Glossy	10	10112089
Frame 2-gang Polar White Glossy	2	10122089
Frame 3-gang Polar White Glossy	2	10132089



10112089

stainless steel / black


Description	Pack qty.	Art No.
Frame 1-gang Stainless Steel/Black	10	10112004
Frame 2-gang Stainless Steel/Black	10	10122004
Frame 3-gang Stainless Steel/Black	10	10132004



10112004

stainless steel / polar white

Description	Pack qty.	Art No.
Frame 1-gang Stainless Steel/Polar White	10	10112014
Frame 2-gang Stainless Steel/Polar White	10	10122014
Frame 3-gang Stainless Steel/Polar White	10	10132014




10112014



182305

Connector


Description	Pack qty.	Art No.
CONNECTION PIECE 1930 BLA	10	182305
CONNECTION PIECE 1930 PW	10	182309



133111

Serie 1930 - self-extinguishing base plate

Description	Pack qty.	Art No.
SELF-EXT.BOT.PL.1930 BROW	10	133111
SELF-EXT.BOT.PL.1930 WHIT	10	133119



100101

Serie 1930 - surface mounting frame

Description	Pack qty.	Art No.
Surface Mount Frame, Black Glossy	10	100101
Surface Mount Frame, Polar White Glossy	95	100109

spacer gland

Description	Pack qty.	Art No.
ABSTAND-STUTZEN 1930/GLAS/PALAZZO	25	1887



1887