

Circuit breakers

	Page
Circuit breakers	3
HRC fuse carriers	4



L12401

Ph/N circuit breakers without indicator

Description	Pack qty.	Art No.
FUSE CARRIER 10A 250V SP&N	12	L12401
FUSE CARRIER 16A 250V SP&N	12	L12501
Fuse carrier 1P+N 20A 1M	12	L12601
FUSE CARRIER 25A 400V SP&N	12	L12701
Fuse carrier 1P+N 32A 1M	12	L12801



L325

Ph/N circuit breakers with indicator

Description	Pack qty.	Art No.
Fuse carrier 1P+N 10A signal light 1M	12	L32401
Fuse carrier 1P+N 16A signal light 1M	12	L32501



LF141

Fuse-cartridge type B


Description	Pack qty.	Art No.
Cartridge fuse 25A - 10.3x31.5mm	10	LF141



L14700

Spare fuse-cartridge

Description	Pack qty.	Art No.
Spare cartridge fuses box	10	L14700



L051

Labels for circuit identification

Description	Pack qty.	Art No.
Labels for circuit indication	10	L05100

L31

Description	Pack qty.	Art No.
Fuse carrier 1P 25A L31 1M	12	LS401
Fuse carrier 1P 25A L31 signal light 1M	12	LS431
Fuse carrier 1P+N 25A L31 2M	6	LS412
Fuse carrier 1P+N 20A L31 1M	12	L40600
Fuse carrier 2P 25A L31 2M	6	LS402
Fuse carrier 3P 25A L31 3M	4	LS403
Fuse carrier 3P+N 25A L31 4M	3	LS404



LS401

L38

Description	Pack qty.	Art No.
Fuse carrier 1P 32A L38 1M	12	LS501
Fuse carrier 1N 32A L38 1M	12	LS509
Fuse carrier 1P 32A L38 signal light 1M	12	LS531
Fuse carrier 1P+N 32A L38 2M	6	LS512
Fuse carrier 1P+N 32A L38 sign. light 1M	12	L53201
Fuse carrier 1P+N 32A L38 1M	12	L50600
Fuse carrier 2P 32A L38 2M	6	LS502
Fuse carrier 3P 32A L38 3M	4	LS503
Fuse carrier 3P+N 32A L38 4M	3	LS504



LS501

Connection kit

Description	Pack qty.	Art No.
Linking kit for fuse carrier(for 1 link)	12	LB026



LB026

L51

Description	Pack qty.	Art No.
Fuse carrier 1P 50A L51 acc. 1.5M	1	LS601
Fuse carrier 1P 50A L51 1.5M	10	LR601
Fuse carrier 1P+N 50A L51 acc. 3M	1	LS612
Fuse carrier 1P+N 50A L51 3M	5	LR612
Fuse carrier 2P 50A L51 acc. 3M	1	LS602
Fuse carrier 2P 50A L51 3M	5	LR602
Fuse carrier 3P 50A L51 acc. 4.5M	1	LS603
Fuse carrier 3P 50A L51 4.5M	3	LR603
Fuse carrier 3P+N 50A L51 acc. 6M	1	LS604
Fuse carrier 3P+N 50A L51 6M	2	LR604



LS601

L58

Description	Pack qty.	Art No.
Fuse carrier 1P 125A L58 acc. 2M	1	LS701
Fuse carrier 1P 125A L58 2M	6	LR701
Fuse carrier 1P+N 125A L58 acc. 4M	1	LS712
Fuse carrier 1P+N 125A L58 4M	3	LR712
Fuse carrier 2P 125A L58 acc. 4M	1	LS702
Fuse carrier 2P 125A L58 4M	3	LR702
Fuse carrier 3P 125A L58 acc. 6M	1	LS703
Fuse carrier 3P 125A L58 6M	2	LR703
Fuse carrier 3P+N 125A L58 acc. 8M	1	LS704
Fuse carrier 3P+N 125A L58 8M	1	LR704



LS701



LS670

Microswitches

Description	Pack qty.	Art No.
Microswitch 1P for fuse carrier L51	1	LS670
Microswitch 3P for fuse carrier L51	1	LS671
Microswitch 1P for fuse carrier L58	1	LS770
Microswitch 3P for fuse carrier L58	1	LS771



LS672

Signal lights 230 V

Description	Pack qty.	Art No.
Signal light 230V fuse carrier L51/L58	1	LS672